

# Ducati Monster 620 maintenance sheet

Monster 620 · 63 PS (46 kW)

Years : 2002-2006      Generated on : 12 October 2026

## Technical specifications

Petrol      Engine code : Ducati Desmodue 618      618 cm<sup>3</sup>      Manual 6

## Maintenance schedule

≈: estimated reference — the vehicle’s service indicator prevails.

| ITEM                            | INTERVAL              |                                                                                                                                                                                   |
|---------------------------------|-----------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Oil and filter change           | ≈ 12,000 km or 1 year | JASO MA or MA2 approved four-stroke motorcycle oil (JASO MB on scooters): an “energy conserving” car oil makes the wet clutch slip. Change it more often in city use or on track. |
| Brake fluid                     | Every 2 years         | Replace the fluid in both circuits (and the hydraulic clutch if fitted), whatever the mileage; dark fluid has absorbed moisture.                                                  |
| Fork oil                        | ≈ 30,000 km           | Fork oil change and seal check; an oil film on the tubes means a seal needs replacing before it contaminates the brake caliper.                                                   |
| Chain kit (chain and sprockets) | ≈ 25,000 km           | Lubricate and check the tension every 500 to 1,000 km and after rain; replace chain and sprockets together when the chain no longer holds its tension or the teeth are hooked.    |
| Timing belts                    | 24,000 km or 2 years  | Replace both belts at whichever comes first, even on a little-used bike: the rubber ages, and a broken belt destroys the engine.                                                  |
| Spark plugs                     | Every 12,000 km       | Replace the full set; worn plugs raise consumption and cause misfires.                                                                                                            |
| Air filter                      | Every 12,000 km       | Replace more often in dusty conditions.                                                                                                                                           |
| Valve clearance                 | Every 12,000 km       | Check and adjust if needed, often together with the plugs; too little clearance burns the valves, too much makes the engine noisy.                                                |

## Service record

| DATE | MILEAGE | WORK DONE | WORKSHOP |
|------|---------|-----------|----------|
|      |         |           |          |
|      |         |           |          |

| DATE | MILEAGE | WORK DONE | WORKSHOP |
|------|---------|-----------|----------|
|      |         |           |          |
|      |         |           |          |
|      |         |           |          |
|      |         |           |          |
|      |         |           |          |
|      |         |           |          |
|      |         |           |          |
|      |         |           |          |
|      |         |           |          |

Indicative intervals and costs: adapt maintenance to the engine, use and manufacturer’s instructions.

Full schedule and updates : <https://auto-karnet.com/en/maintenance/ducati/monster/monster-620-2002-2006/620-63>